

## HELPFUL HINTS FOR BEST RESULTS WITH YOUR MONOMATIC SANITATION SYSTEM

1. When you have emptied your Monomatic sanitation system it is best to flush it out by inserting a garden hose directly into the exit of the bowl (NOTE: Take care not to disengage the plastic-cloth splash restrictor which is attached to the neck of the bowl by means of an elastic band). Close the valve and fill the tank with water (surface of fluid will be visible at bottom of bowl) add 1/2 cup of Vanish Bowl Cleaner or a cold water detergent and flush several times. Allow this solution to remain in the tank for 30 minutes and rinse thoroughly. Vanish Bowl Cleaner and cold water detergents are generally available at most supermarkets throughout the country. WHILE THESE OPERATIONS ARE NOT ESSENTIAL, they are, nevertheless, a tremendous aid in keeping your Monomatic sanitation system clean, and therefore more serviceable.
2. Use only a disintegratable type of toilet tissue--not a facial quality wet-strength type tissue. The inexpensive, white tissues are better for this purpose than the colored. When extending the capacity of self-containment by means of a holding tank, you will want to use a minimum amount of rinse water. If possible, use a hose to increase pressure. Model W includes a water inlet fitting which allows a high pressure nozzle-like cleaning action to take place within the tank so that very little water is required. Existing Model A (manually-filled) may be easily converted to Model W by means of the Monovac Model 4G, optional accessory kit--see your dealer or contact Monogram for full details. Remember, where possible, to thoroughly rinse out any cleaning solution prior to recharging. Like your household toilet, normal cleaning brings best results.
3. Hospitals have long ago discovered the best way to utilize a static sanitation device. In hospital management journals, therefore, they list as standard operating procedure for all nurses handling these devices to lay a few pieces of toilet tissue in the bowl prior to use. FOLD TISSUE IN FORM OF A "V" AS SHOWN. All human body chemistry is different and certain individuals will find this a perfect solution to fast removal of waste matter from the bowl.
4. If you are not getting a vigorous flushing action it could be that your battery is low, or something is interfering with your power supply. Remember that the Monomatic sanitation system must be connected directly by a minimum #14 gauge wire AS A SEPARATE CIRCUIT to a 12 volt DC power source. No other electrical appliance or lights should be connected to the Monomatic sanitation system circuit. While the unit will work perfectly well, its less than vigorous flush will interfere with the cycling process and might even shorten the length of the odor and color control.

